



# Zirconia-Based Materials for Catalytic Conversions

## Our capability

Luxfer MEL Technologies supplies both doped and undoped zirconium compounds (hydroxides and oxides) for a use in a wide range of catalytic applications.

Materials are solid powders, with tunable properties resulting from our proprietary manufacturing processes. These are carried out at multi-ton scale.

LMT also supplies zirconium solutions that are frequently used as binders (or indeed a Zr-source) in catalyst forming.

## Advantages

### Easy separation from reaction media

Catalysts can be easily separated from the reaction media.

### High activity / low temperature operation

Good interaction with supported metals, and properties can be modified by dopants.

### Structure

They have developed (tunable) porosity and defined crystalline structure.

### Stability

Particularly under hydrothermal (aqueous) conditions, ideal for 'green' processes.

## Reusability

Catalysts can be used several times during reaction cycle.

## Environmentally friendly

Zirconia-based materials do not release any halogen containing or other compounds which might corrode equipment, impact eco-system.

## Typical dopants

Dopant	Property
Undoped	Amphoteric
SO <sub>4</sub> , WO <sub>3</sub>	Strong Acidity
SiO <sub>2</sub> , Al <sub>2</sub> O <sub>3</sub>	Mild Acidity
MgO, La <sub>2</sub> O <sub>3</sub>	Basic
CeO <sub>2</sub>	Redox

\*Other dopants can potentially be worked with, e.g. transition metal oxides, other rare-earth oxides, SnO<sub>2</sub>, Nb<sub>2</sub>O<sub>5</sub>.

Multiple dopants/combinations are also manufactured on a regular basis.

## Physical properties


	Synthetic Route			
	C1	C3	C4	New
D <sub>50</sub> (µm)	~1 (A) ~25 (B)	~5	~25 (broad)	~20 (broad)
Porosity	Low	Med	High	v.High
Surface area	Med	Med	High	v.High
Active sites	Med	Med	High	v.High

\*Active sites may refer to acidity for example.

## Applications

Typically has involved isomerisation of alkanes in gasoline upgrading (super-acid).

However, zirconia-based supports have attracted a lot of interest for “green” processes, for example cellulose conversion<sup>14</sup>. Other examples are shown below:



## References

- Lilga, M. A. et al., *Catalysis Today*, 302, 2018, 80-86
- Huq, N. A., et al., *PNAS*, 118 (13), 2021, e2023008118
- Coronado, I., et al., *Applied Catalysis A : General*, 567, 2018, 112-121
- Dos Santos, V. C., et al., *Applied Catalysis B : Environmental*, 162, 2015, 75-84
- Sani, Y. M., et al., *Applied Catalysis A : General*, 470, 2014, 140-161
- Li, K, and Chen, J. G., *ACS Catalysis*, 9, 2019, 7840-7861
- Ye, R., et al., *Nature Communications*, 10, 2019, Article No. 5698
- Sache, E. L., et al., *ACS Sustainable Chemistry & Engineering*, 11, 2020, 4614-4622
- Frontera, P., et al., *Catalysts*, 7 (2), 2017, 59
- Fakeeha, A. H., et al., *Journal of Saudi Chemical Society*, 25, 2021, 101244
- Almustapha, M. N., et al., *Journal of Analytical and Applied Pyrolysis*, 125, 2017, 296-303
- Mounguengui-Diallo, M., et al., *Applied Catalysis A : General*, 551, 2018, 88-97
- Schade, O. R., et al., *Advanced Synthesis & Catalysis*, 362, 2020, 5681-5696
- Nguyen, V. C., et al., *Molecular Catalysis*, 476, 2019, 110518

Discover more at

[www.luxfermeltechnologies.com](http://www.luxfermeltechnologies.com)

<sup>†</sup> The information contained within is meant as a guideline only

Copyright © Luxfer MEL Technologies 2023. The information provided within this document is aimed to assist manufacturers and other interested parties in the use of Luxfer MEL Technologies products. Luxfer MEL Technologies accepts no liability in whole or in part from use and interpretation of the data herein. All information is given in good faith but without warranty. Freedom from patent rights must not be assumed. Health and Safety information is available for all Luxfer MEL Technologies products. **DS-1075-0523**

**Luxfer MEL Technologies**  
Elektron Technology Centre  
Lumns Lane, Manchester, M27 8LN, UK  
T +44 (0) 161 911 1000

**Luxfer MEL Technologies**  
500 Barbertown Point Breeze Road  
Flemington, NJ 08822, USA  
T +1 908 782 5800